

**MOVING HEAD T180C :**

**DMX channel's functions and their values (19DMX channels):**

MODE/CHANNEL					VALUE	FUNCTION	
5CH	6CH	8CH	13CH	19CH			
1	1	1	1	1		<b>RED LED :</b>	
					0-255	RED ( 0-Black , 255-100% Red )	LED红色从0~100%
				2		<b>RED LED FINE :</b>	
					0-255	RED FINE Adjustment	LED红色微调
2	2	2	2	3		<b>GREEN LED :</b>	
					0-255	GREEN ( 0-Black , 255-100% Green )	LED绿色从0~100%
				4		<b>GREEN LED FINE :</b>	
					0-255	GREEN FINE Adjustment	LED绿色微调
3	3	3	3	5		<b>BLUE LED :</b>	
					0-255	BLUE ( 0-Black , 255-100% Blue )	LED蓝色从0~100%
				6		<b>BLUE LED FINE :</b>	
					0-255	BLUE FINE Adjustment	LED蓝色微调
4	4	4	4	7		<b>MINT LED :</b>	
					0-255	MINT ( 0-Black , 255-100% Mint )	LED薄荷绿色从0~100%
				8		<b>MINT LED FINE :</b>	
					0-255	MINT FINE Adjustment	LED薄荷绿色微调
5	5	5	5	9		<b>AMBER LED :</b>	
					0-255	AMBER ( 0-Black , 255-100% Amber )	LED琥珀色从0~100%
				10		<b>AMBER LED FINE :</b>	
					0-255	AMBER FINE Adjustment	LED琥珀色微调
		6	6	11	0	<b>COLOR TEMPERATURE :</b>	
					1-255	NO FUNTION Color Temperature(1-2,700K,255-5,600K)	无功能 色温从2700K~5600K
		7	7	12	0	<b>COLOR MACROS:</b>	
					1-7	NO FUNCTION	无功能
					8-15	Color Macro 01	混色效果
					16-23	Color Macro 02	混色效果
					24-31	Color Macro 03	混色效果
					32-39	Color Macro 04	混色效果
					40-47	Color Macro 05	混色效果
					48-55	Color Macro 06	混色效果
					56-63	Color Macro 07	混色效果
					64-71	Color Macro 08	混色效果
					72-79	Color Macro 09	混色效果
					80-87	Color Macro 10	混色效果
					88-95	Color Macro 11	混色效果
					96-103	Color Macro 12	混色效果
					104-111	Color Macro 13	混色效果
					112-119	Color Macro 14	混色效果
					120-127	Color Macro 15	混色效果
					128-135	Color Macro 16	混色效果
					136-143	Color Macro 17	混色效果
					144-151	Color Macro 18	混色效果
					152-159	Color Macro 19	混色效果
					160-167	Color Macro 20	混色效果
					168-175	Color Macro 21	混色效果
					176-183	Color Macro 22	混色效果
					184-191	Color Macro 23	混色效果
					192-199	Color Macro 24	混色效果
					200-207	Color Macro 25	混色效果
						Color Macro 26	混色效果

					208-215 216-223 224-231 232-239 240-247 248-255	Color Macro 27 Color Macro 28 Color Macro 29 Color Macro 30 Color Macro 31 Color Macro 32	混色效果 混色效果 混色效果 混色效果 混色效果 混色效果
			8	13	0 1-30 31-60 61-90 91-120 121-150 151-180 181-210 211-255	<b><u>INTERNAL PROGRAM MACROS :</u></b> NO FUNCTION Internal Program 01 Internal Program 02 Internal Program 03 Internal Program 04 Internal Program 05 Internal Program 06 Internal Program 07 Internal Program 08	无 内置程序1 内置程序2 内置程序3 内置程序4 内置程序5 内置程序6 内置程序7 内置程序8
			9	14	0-31 32-63 64-95 96-127 128-159 160-191 192-223 224-255	<b><u>STROBE :</u></b> LEDS OFF LEDS ON Strobe Effect SLOW to FAST LEDS ON Pulse Effect In Sequences LEDS ON Random Strobe Effect SLOW to FAST LEDS ON	关闭 打开光 同步频闪从慢到快 打开光 脉冲同步频闪 打开光 异步频闪从慢到快 打开光
	6	8	10	15	0-255	<b><u>DIMMER INTENSITY :</u></b> Intensity 0 to 100%	调光(或内置程序速度)从0到100%
				16	0-255	<b><u>DIMMER FINE :</u></b> FINE Intensity 0 to 100%	调光微调
			11	17	0-20 21-40 41-60 61-80 81-100 101-255	<b><u>DIMMING CURVES :</u></b> STANDARD STAGE TV ARCHI TECTURAL THEATRE Default to Unit Dimming Curve Setting	标准模式 舞台模式 电视模式 建筑模式 剧院模式 缺省模式
			12	18	0-189 190-255	<b><u>COLOR ENABLE :</u></b> NO Function Enable (Turn ON) EDIT WHITE BALANCE M	无用 编辑和存储白平衡使能
			13	19	0-189 190-254 255	<b><u>Color Mode:</u></b> NO Function EDIT (Set) a New WHITE BALANCE STORE (Save) a New WHITE BALANCE	无用 编辑新的白平衡 存储编辑好的白平衡