

C5:

DMX channel's functions and their values (28 DMX channels):

Mode/Channel			Value	Function	
12CH	20CH	28CH			
1		1	0-255	<u>Red LED -all arrays :</u> Red (0-Black , 255-100% Red)	LED红色从0~100%
2		2	0-255	<u>Green LED-all arrays :</u> Green (0-Black , 255-100% Green)	LED绿色从0~100%
3		3	0-255	<u>Blue LED -all arrays :</u> Blue (0-Black , 255-100% Blue)	LED蓝色从0~100%
4		4	0-255	<u>Deep Blue LED -all arrays :</u> Deep_Blue (0-Black , 255-100% White)	LED深蓝色从0~100%
5		5	0-255	<u>Hyper RED LED -all arrays :</u> Amber (0-Black , 255-100% White)	LED超红色从0~100%
6		6	0-255	<u>Yellow LED -all arrays :</u> Yellow (0-Black , 255-100% White)	LED黄色从0~100%
7		7	0-255	<u>Cyan LED -all arrays :</u> Cyan (0-Black , 255-100% White)	LED青色从0~100%
8		8	0-255	<u>White LED -all arrays :</u> White (0-Black , 255-100% White)	LED白色从0~100%
	1	9	0-255	<u>Red LED -all arrays 1:</u> Red (0-Black , 255-100% Red)	LED红色从0~100%
	2	10	0-255	<u>Green LED -all arrays 1:</u> Green (0-Black , 255-100% Red)	LED绿色从0~100%
	3	11	0-255	<u>Blue LED -all arrays 1:</u> Blue (0-Black , 255-100% Red)	LED蓝色从0~100%
	4	12	0-255	<u>Deep Blue LED -all arrays 1:</u> Deep_Blue (0-Black , 255-100% Red)	LED深蓝色从0~100%
	5	13	0-255	<u>Hyper RED LED -all arrays 1:</u> Amber (0-Black , 255-100% Red)	LED超红色从0~100%
	6	14	0-255	<u>Yellow LED -all arrays 1:</u> Yellow (0-Black , 255-100% Red)	LED黄色从0~100%
	7	15	0-255	<u>Cyan LED -all arrays 1:</u> Cyan (0-Black , 255-100% Red)	LED青色从0~100%
	8	16	0-255	<u>White LED -all arrays 1:</u> White (0-Black , 255-100% Red)	LED白色从0~100%
	9	17	0-255	<u>Red LED -all arrays 2:</u> Red (0-Black , 255-100% Red)	LED红色从0~100%
	10	18	0-255	<u>Green LED -all arrays 2:</u> Green (0-Black , 255-100% Red)	LED绿色从0~100%
	11	19	0-255	<u>Blue LED -all arrays 2:</u> Blue (0-Black , 255-100% Red)	LED蓝色从0~100%
	12	20	0-255	<u>Deep Blue LED -all arrays 2:</u> Deep_Blue (0-Black , 255-100% Red)	LED深蓝色从0~100%

	13	21	0-255	<u>Hyper RED LED -all arrays 2:</u> Amber (0-Black , 255-100% Red)	LED超红色从0~100%
	14	22	0-255	<u>Yellow LED -all arrays 2:</u> Yellow (0-Black , 255-100% Red)	LED黄色从0~100%
	15	23	0-255	<u>Cyan LED -all arrays 2:</u> Cyan (0-Black , 255-100% Red)	LED青色从0~100%
	16	24	0-255	<u>White LED -all arrays 2:</u> White (0-Black , 255-100% Red)	LED白色从0~100%
9	17	25	0 1-30 31-60 61-90 91-120 121-150 151-180 181-210 211-255	<u>internal programs:</u> No function internal program 1 internal program 2 internal program 3 internal program 4 internal program 5 internal program 6 internal program 7 internal program 8	无 内置程序1 内置程序2 内置程序3 内置程序4 内置程序5 内置程序6 内置程序7 内置程序8
10	18	26	0-31 32-63 64-95 96-127 128-159 160-191 192-223 224-255	<u>Shutter, strobe:</u> Led trun off Led turn on Strobe effect slow to fast Led turn on Pulse-effect in sequences Led turn on Random strobe effect slow to fast Led turn on	关闭 打开光 同步频闪从慢到快 打开光 脉冲同步频闪 打开光 异步频闪从慢到快 打开光
11	19	27	0-255	<u>Dimmer intensity:</u> Intensity 0 to 100%	调光(或内置程序速度)从0到100%
12	20	28	0-20 21-40 41-60 61-80 81-100 101-255	<u>Dim Modes</u> Standard Stage TV Architectoral Theatre Default to Unit Setting	标准模式 舞台模式 电视模式 建筑模式 剧院模式 缺省模式